

Bravo Still

Extract fans

- Casing material: Plastic
- Humidity sensor
- Motion sensor

Lineup	Maximum airflow, m³/h	Motion sensor	Pull cord	Humidity sensor	Timer	Number of speeds
Bravo Still 100	70	✗	✗	✗	✗	1
Bravo Still 100 S	70	✗	✓	✗	✗	1
Bravo Still 100 T	70	✗	✗	✗	Turn off timer	1
Bravo Still 100 ST	70	✗	✓	✗	Turn off timer	1
Bravo Still 100 H	70	✗	✗	✓	Turn off timer	1
Bravo Still 100 SH	70	✗	✓	✓	Turn off timer	1
Bravo Still 100 IR	70	✓	✗	✗	Turn off timer	1

 Bravo Still 125	115	✗	✗	✗	✗	1
 Bravo Still 125 S	115	✗	✓	✗	✗	1
 Bravo Still 125 T	115	✗	✗	✗	Turn off timer	1
 Bravo Still 125 ST	115	✗	✓	✗	Turn off timer	1
 Bravo Still 125 H	115	✗	✗	✓	Turn off timer	1
 Bravo Still 125 SH	115	✗	✓	✓	Turn off timer	1
 Bravo Still 125 IR	115	✓	✗	✗	Turn off timer	1
 Bravo Still 150	235	✗	✗	✗	✗	1
 Bravo Still 150 S	235	✗	✓	✗	✗	1
 Bravo Still 150 T	235	✗	✗	✗	Turn off timer	1
 Bravo Still 150 ST	235	✗	✓	✗	Turn off timer	1
 Bravo Still 150 H	235	✗	✗	✓	Turn off timer	1
 Bravo Still 150 SH	235	✗	✓	✓	Turn off timer	1

 Bravo Still 150 IR	235	✓	✗	✗	Turn off timer	1
 Bravo Still Chrome 100	70	✗	✗	✗	✗	1
 Bravo Still Chrome 100 S	70	✗	✓	✗	✗	1
 Bravo Still Chrome 100 T	70	✗	✗	✗	Turn off timer	1
 Bravo Still Chrome 100 ST	70	✗	✓	✗	Turn off timer	1
 Bravo Still Chrome 100 H	70	✗	✗	✓	Turn off timer	1
 Bravo Still Chrome 100 SH	70	✗	✓	✓	Turn off timer	1
 Bravo Still Chrome 100 IR	70	✓	✗	✗	Turn off timer	1
 Bravo Still Chrome 125	115	✗	✗	✗	✗	1
 Bravo Still Chrome 125 S	115	✗	✓	✗	✗	1
 Bravo Still Chrome 125 T	115	✗	✗	✗	Turn off timer	1
 Bravo Still Chrome 125 ST	115	✗	✓	✗	Turn off timer	1
 Bravo Still Chrome 125 H	115	✗	✗	✓	Turn off timer	1

 Bravo Still Chrome 125 SH	115	✗	✓	✓	Turn off timer	1
 Bravo Still Chrome 125 IR	115	✓	✗	✗	Turn off timer	1
 Bravo Still Chrome 150	235	✗	✗	✗	✗	1
 Bravo Still Chrome 150 S	235	✗	✓	✗	✗	1
 Bravo Still Chrome 150 T	235	✗	✗	✗	Turn off timer	1
 Bravo Still Chrome 150 ST	235	✗	✓	✗	Turn off timer	1
 Bravo Still Chrome 150 H	235	✗	✗	✓	Turn off timer	1
 Bravo Still Chrome 150 SH	235	✗	✓	✓	Turn off timer	1
 Bravo Still Chrome 150 IR	235	✓	✗	✗	Turn off timer	1
 Bravo Still Platinum 100	70	✗	✗	✗	✗	1
 Bravo Still Platinum 100 S	70	✗	✓	✗	✗	1
 Bravo Still Platinum 100 T	70	✗	✗	✗	Turn off timer	1
 Bravo Still Platinum 100 ST	70	✗	✓	✗	Turn off timer	1

 Bravo Still Platinum 100 H	70	✗	✗	✓	Turn off timer	1
 Bravo Still Platinum 100 SH	70	✗	✓	✓	Turn off timer	1
 Bravo Still Platinum 100 IR	70	✓	✗	✗	Turn off timer	1
 Bravo Still Platinum 125	115	✗	✗	✗	✗	1
 Bravo Still Platinum 125 S	115	✗	✓	✗	✗	1
 Bravo Still Platinum 125 T	115	✗	✗	✗	Turn off timer	1
 Bravo Still Platinum 125 ST	115	✗	✓	✗	Turn off timer	1
 Bravo Still Platinum 125 H	115	✗	✗	✓	Turn off timer	1
 Bravo Still Platinum 125 SH	115	✗	✓	✓	Turn off timer	1
 Bravo Still Platinum 125 IR	115	✓	✗	✗	Turn off timer	1
 Bravo Still Platinum 150	235	✗	✗	✗	✗	1
 Bravo Still Platinum 150 S	235	✗	✓	✗	✗	1
 Bravo Still Platinum 150 T	235	✗	✗	✗	Turn off timer	1

 Bravo Still Platinum 150 ST	235	✗	✓	✗	Turn off timer	1
 Bravo Still Platinum 150 H	235	✗	✗	✓	Turn off timer	1
 Bravo Still Platinum 150 SH	235	✗	✓	✓	Turn off timer	1
 Bravo Still Platinum 150 IR	235	✓	✗	✗	Turn off timer	1